

## Software for COMET TPrints and GSM modems

code: SWR001

Software for COMET dataloggers series Rxxxx, Sxxxx, Gxxxx, Dxxxx, ZV.



### Technical data

|                                              |     |
|----------------------------------------------|-----|
| GENERAL FEATURES                             |     |
| Technical support                            | Ano |
| Languages in program                         | Ano |
| PROGRAM SETTINGS                             |     |
| Communication settings (basic settings)      | Ano |
| Data presentation (basic settings)           | Ano |
| Communication settings (extended settings)   | Ano |
| Data presentation (extended settings)        | Ano |
| Data storing (Folders and files settings)    | Ano |
| M2M connection settings                      | Ano |
| Autodownload                                 | Ano |
| DATA HANDLING                                |     |
| Download record from the data logger         | Ano |
| Open record from the file                    | Ano |
| Show data into the table                     | Ano |
| Data export to DBF (basic export)            | Ano |
| Data export to XLS (basic export)            | Ano |
| Data export to DBF (extended options)        | Ano |
| Data export to XLS (extended options)        | Ano |
| Print data from the table (basic print)      | Ano |
| Print data from the table (extended options) | Ano |
| Statistics                                   | Ano |
| GRAPHICS                                     |     |
| Simple graph                                 | Ano |
| Graph                                        | Ano |
| Simple graph print                           | Ano |
| Graph print                                  | Ano |

|                                                 |     |
|-------------------------------------------------|-----|
| Graph export to PDF                             | Ano |
| DATALOGGER HANDLING                             |     |
| Datalogger configuration                        | Ano |
| Datalogger memory erase                         | Ano |
| Battery exchange                                | Ano |
| Save configuration to the file                  | Ano |
| Read configuration from the file                | Ano |
| COMET DATABASE                                  |     |
| Data export to the COMET Database               | Ano |
| Data download with export to the COMET Database | Ano |
| Autodownload with export to the COMET Database  | Ano |